

Putter Length to Weight Recommendations

The following table provides a guide when changing the length and/or weight of your Scotty Cameron Studio Select putter.

- Every Studio Select putter has two factory interchangeable weights. The individual gram weight of each weight is listed here.
- Swingweights are listed with a +/- 2 swingweight point range, as the actual swingweight of any given putter may vary within these ranges.
- One inch of shaft equals 6 swingweight points, so please take that into account when changing shaft lengths.

Studio Select	Lighter	Standard	Heavier	Extra Heavy
36"	N/A	5g weights (D7-D9)	10g weights (E2-E4)	15g weights (E7-E9)
35"	5g weights (D1-D3)	10g weights (D6-D8)	15g weights (E1-E3)	20g weights (E6-E8)
34"	10g weights (C7-C9)	15g weights (D2-D4)	20g weights (D7-D9)	25g weights (E2-E4)
33"	15g weights (C4-C6)	20g weights (C9-D1)	25g weights (D4-D6)	30g weights (D9-E1)
32"	20g weights (C3-C5)	25g weights (C8-D0)	30g weights (D3-D5)	N/A
31"	25g weights (C2-C4)	30g weights (C7-C9)	N/A	N/A

Lighter = Subtracting 10 total grams of head weight from Standard, which takes away 5 swingweight points.

Heavier = Adding 10 total grams additional head weight than Standard, which adds 5 swingweight points.

Extra Heavy = Adding 20 total grams additional head weight than Standard, which adds 10 swingweight points.